



HP Pavilion 14-c015dx Chromebook Battery Replacement

This guide will help you remove and replace your battery for the laptop.

Written By: Alexandra Garro



INTRODUCTION


This guide will walk you through the steps to remove and replace the battery. This is a very easy fix because the battery is on the outside of the laptop and simple to remove: There are no other components blocking your access to battery. Here is a link to buy a replacement battery: [Dr. Power Battery](#)

Step 1 — Battery



- Set the lock switch to the orange unlocked position.

Step 2



- Slide the right side switch to the left so the battery sign does not show.
- Once this switch is pushed, the battery will pop out slightly and you can pull the battery out completely.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-05 07:46:18 PM.